




1.1. Stove Parts

- A. Upper connection opening
- B. Rear connection opening
- C. Soot opening
- D. Stove door
- E. Ash box




WX096



ZKIP-720

Z2ES-125



ZKIP-721


Z2ES-127



ZKIP-140




ZKIP-170
(M1/M3)



WX048



ZTS-36



ZKIP-10

Stove parts. Note! Only use replacement parts recommended by the manufacturer. Unauthorised modification of the stove is prohibited.